

## **IG9101 – 1kW Panel Heater**



Problem	Possible Cause	Solution
The heater does not work.	<ol> <li>Not properly plugged into the mains wall socket.</li> <li>Not switched on</li> <li>No electricity in the mains wall socket.</li> <li>Timer not set to switch on</li> </ol>	<ol> <li>Plug in firmly.</li> <li>Make sure appliance is switched on.</li> <li>Check fuse or breaker.</li> <li>Adjust timer accordingly</li> </ol>
The heater is getting too hot	<ol> <li>Inadequate air flow</li> <li>Heat setting too high</li> <li>Vents are blocked</li> </ol>	<ol> <li>Make sure there is circulating air in the room</li> <li>Adjust heat settings accordingly</li> <li>Make sure all vents are clear and free from obstruction</li> </ol>
The heater is not heating up	1. Timer has not been set	Set the timer accordingly or switch to manual setting.